

Battery Installation Instructions

1. Unscrew the thermos cover. Be careful not to tip or spill the thermos - it is best to install the batteries when the thermos is empty
2. Unzip the insulated sleeve and lift over the top of the thermos to expose the battery compartment (on side). Remove the battery door
3. Insert 4 AA batteries (included with purchase) – be careful to insert the batteries with the proper orientation (+/-). Do not mix old and new batteries, and do not mix alkaline batteries with rechargeable batteries.
4. Replace the battery compartment door, slide the top of the insulated sleeve over the top of the thermos, and zipper the insulated sleeve closed.
5. Screw the thermos cover back on – check to be sure it is secure, but be careful not to over-tighten

Dencco, Inc.

21 Northwestern Drive
Salem, NH 03079
Toll Free: 1-800-336-6264
NH: (603) 898-0004
customerservice@clubchamp.com